



Stopping the device – stop ABCD





2

3

4

5



Stop the device(s)



- Press and hold the Stop button for 5 seconds.
- The Shipment LED will light up for 3 seconds to indicate a successful button press.
- The status on the display will change from Shipping to Stopping, then Stopped.

Check Alarm status



NO Alarm





- If there has been a temperature excursion, the Alarm LED will light up for 3 seconds before turning off, and a bell icon will remain visible in the top right corner of the display.
- Refer to your SOP and proceed accordingly.

Check Battery level





>10%





- Charge the device by plugging it into a Controlant charging station/USB charging adapter/computer USB port until it reaches a minimum 15% battery level.
- Note: Fully charging the device from depleted takes 6 hours.

Check Cloud connection status









- The device will show a successful Cloud connection. If not, press the stop button again in an area with stronger cellular reception.
- If unsuccessful again, complete a manual data upload at upload.controlant.com or contact Controlant Support for assistance.

Check calibration Date





- Controlant devices are calibrated annually.
 Check the back of the device for the last calibration date.
- If the device has surpassed its calibration period, contact Controlant Support.

Return the devices



Place the device(s) in the assigned area for Controlant devices and follow the agreed process to return them when appliable, as they are reusable.